


HOME DECORATORS C O L L E C T I O N

BF-24802 MSL CORNER CRAFT TABLE 31H X58W X41"D BX2

INV#07952

ASSEMBLY INSTRUCTIONS













Made In China





















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST

A  TOP PANEL-1PC	B  LEFT FRAME-1PC	C  RIGHT FRAME-1PC
D  BACK PANELS-2PCS	E  BACK STAND PANEL-1PC	F  DOWN ACROSS PANELS-2PCS
G  FRONT FRAME-1PC	H  SMALL LEFT SIDE PANEL-1PC	I  SMALL RIGHT SIDE PANEL-1PC
J  SMALL STAND PANEL-1PC	K  SMALL BOTTOM PANEL-1PC	L  LEFT DRAWER PANEL SIDES-2PCS

M  <p>RIGHT DRAWER PANEL SIDES-2PCS</p>	N  <p>DRAWER PANEL BACKS-2PCS</p>	O  <p>DRAWER PANEL BOTTOMS-2PCS</p>
P  <p>LEFT DRAWER PANEL FRONT-1PC</p>	Q  <p>SMALL DRAWER ACROSS PANELS-2PCS</p>	R  <p>SMALL DRAWER STAND PANELS-4PCS</p>
S  <p>RIGHT DRAWER PANEL FRONT-1PC</p>	T  <p>CAM-TOOL-1PC</p>	U <p>8mm× 5/8"</p>  <p>SCREWS-2PCS</p>
V <p>11mm× 1-1/2"</p>  <p>SCREWS-4PCS</p>	W  <p>ALLEN WRENCH-1PC</p>	X  <p>FEET-9PCS</p>
Y  <p>DOWELS-4PCS</p>	Z <p>8mm× 1-1/4"</p>  <p>SCREWS-5PCS</p>	A1 <p>6mm× 3/8"</p>  <p>SCREWS-24PCS</p>
B1  <p>OUTER SLIDERS-4PCS</p>	C1  <p>INNER SLIDES-4PCS</p>	D1  <p>CAM-BOLTS-28PCS</p>

E1



CAM-LOCKS-28PCS

F1



KNOBS-2PCS


G1



NUTS-4PCS

H1

6mm×1"



SCREWS-16PCS

I1


11mm×1"



SCREWS-6PCS



NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

HOW TO SEPARATE GLIDES






PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDE

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1) . ASSEMBLE THE PANELS(D/E/F) .

- ROTATE 4 CAM-BOLTS(D1) AND INSERT THE 2 DOWELS(Y) INTO THE HOLES IN THE PANEL(B/E) .
- PLACE THE 4 CAM-BOLTS(D1) INTO THE HOLES IN THE PANEL(D) AND ATTACH USING 4 CAM-LOCKS(E1) .
- ROTATE 2 SCREWS(Z) INTO THE HOLES IN THE PANEL(F) .





2) . ASSEMBLE THE PANELS(D/E/F) .

- ROTATE 4 CAM-BOLTS(D1) AND INSERT THE 2 DOWELS(Y) INTO THE HOLES IN THE PANEL(C/E) .
- PLACE THE 4 CAM-BOLTS(D1) INTO THE HOLES IN THE PANEL(D) AND ATTACH USING 4 CAM-LOCKS(E1) .
- ROTATE 2 SCREWS(Z) INTO THE HOLES IN THE PANEL(F) .




3) . ASSEMBLE THE TOP PANEL(A).

- ROTATE THE 14 CAM-BOLTS(D1) INTO THE HOLES IN THE TOP PANEL(A) .
- PLACE THE 14 CAM-BOLTS(D1) INTO THE HOLES IN THE PANEL(B/C/D/E) AND ATTACH USING 14 CAM-LOCKS(E1) .




4) . ASSEMBLE THE OUTER SLIDERS(B1).

- ATTACH THE OUTER SLIDERS(B1) TO SMALL STAND PANEL(J) USING 6 SCREWS(A1).




5) . ASSEMBLE THE OUTER SLIDER(B1).

- ATTACH THE OUTER SLIDER(B1) TO SMALL LEFT SIDE PANEL(H) USING 3 SCREWS(A1) .




6) . ASSEMBLE THE OUTER SLIDER(B1).

- ATTACH THE OUTER SLIDER(B1) TO SMALL RIGHT SIDE PANEL(I) USING 3 SCREWS(A1) .



7) . ASSEMBLE THE SMALL BOTTOM PANEL(K) .


- INSERT THE 4 NUTS(G1) INTO THE HOLES IN THE SMALL BOTTOM PANEL(K) .
- ATTACH THE PANEL(H/I) TO SMALL BOTTOM PANEL(K) USING 4 SCREWS(V) .
- ATTACH THE SMALL STAND PANEL(J) TO SMALL BOTTOM PANEL(K) USING 1 SCREW(Z) .



8) . ASSEMBLE THE FRONT FRAME(G) .


- ROTATE 6 CAM-BOLTS(D1) INTO THE HOLES IN THE FRONT FRAME(G) .
- PLACE THE 6 CAM-BOLTS(D1) INTO THE HOLES IN THE PANEL(H/I/J) AND ATTACH USING 6 CAM-LOCKS(E1) .

THESE FEET CAN FLUCTUATE, EXTENT ABOUT 5MM.




9) . ASSEMBLE THE FRAME AND FEET(X).

- ATTACH THE FRAME TO TOP PANEL(A) USING 6 SCREWS(I1).
- ROTATE THE 9 FEET(X) INTO THE HOLES IN THE PANEL(B/C/E).




10) .ASSEMBLE THE DRAWERS.

- ATTACH DRAWER PANEL SIDES(L/M) TO DRAWER PANEL FRONT(P/S) USING 8 SCREWS(H1) .
- ATTACH 2 KNOBS(F1) TO DRAWER PANEL FRONT(P/S) USING 2 SCREWS(U) .
- INSERT THE DRAWER PANEL BOTTOMS(O) INTO THE SLOTS IN THE DRAWER PANEL SIDES(L/M) .
- ATTACH DRAWER PANEL BACKS(N) BETWEEN LEFT DRAWER PANEL SIDES(L) AND RIGHT DRAWER PANE SIDES(M) USING 8 SCREWS(H1) .



11) .ASSEMBLE THE INNER SLIDES(C1) AND PANELS(Q/R) .

- ATTACH THE INNER SLIDERS(C1) TO DRAWER SIDE PANEL(L/M) USING 6 SCREWS(A1) .
- INSERT THE PANELS(Q/R) IN THE DRAWERS .



12) ASSEMBLE THE DRAWERS.

- INSERT 2 DRAWERS INTO THE SLIDERS.